



1 Elevator IC Card Control System Overview
1.1 System Overview
1.2.168System Functions
1.3 System Usage Connection
1.4 System Usage Procedures
2 Usage Description for Products related to Elevator Cabin
2.1 Elevator IC Card Controller Installation
2.2 Elevator IC Card Control and setting up floor access with controlled and uncontrolled function
2.2.14C IC Card Enable
2.2.2 Controlled/Uncontrolled IC Card Control Function Enable for Individual Floor
2.3 Usage of IC Card Control Box
2.3 Jumper Setting


1 metre
RF Cable
Thumb
Screw
Front View
Installation Instruction








Property Management Company
Company Cards
B1
Unit 1
1-1
Unit 2
2-1
2-2
Unit 3
edit
delete


Elevator Controller Config
Controller ID: 2
Name: Controller 2
Total Station:


B1
Unit 2
2-1
2-2
Unit 1



Card ID	Owner	Mobile	Householder	Remain	Card Type	Manipulation
CA62BD33	Allen	0430708	Vanke City-B1-Unit 2-2-1	0 Times	User Card	Loss Delete


IC Card Mana
ssential information
Card ID
CA764AE3
Card Type
User
Public
Setting
Owner
Mobile
Household
Country Garden-20=-u 1-1-1
admin
Operation time
Expiry da
2019-01-24 (Overdue)
Auxiliary report of
Choose a lost card